

Failure to avoid the following potential hazardous situation

could result in serious injury.

Choking Hazard

This product and its packaging contain small parts and are Not for children under 3 years old.

Battery Warnings

If these guidelines are not followed, the battery may have a shortened life span or may present a risk of damage to the device, fire, chemical burn, electrolyte leak and/or injury.

Do not use sharp object to remove the battery

Do not puncture or incinerate the device or battery.

Do not leave the device exposed to a heat source or high temperatures such as in the sun in an unattended vehicle. To prevent damage, do not store the device under direct sunlight or remove the device form the

Do not disassemble, puncture, or damage the battery.

Do not immerse or expose the device to water or other liquids, fire.

explosion or other hazards When storing the device for an extended period of time, store under the following environmental conditions temperature range: 32° - 77°F

Do not operate the device outside of the following environemntal conditions, temapeture range: -4° - 131°F(-20° - 55°C).

If using an AC charger or an external battery charger only use the accessory approved for your product. Keep the Battery away from

Pacemakers and Other Medical Devices

of Radio frequency (RF) energy for data communications. To device has been tested and found compliant with energy (RF) can interfere with some electronic devices. applicable regulations as part of the radio certifical precaution guidelines to minimize the risk of interference with pacemakers operation:

Keep the device at the opposite side of the body where t pacemaker is implanted to add some extra distance between the pacemaker and the device. Try to maintain a distance of at least 6 inches (15cm) between the pacemaker and the device.

Avoid placing a turned-on device next to the pacemaker implant (e.g. don't carry the device in a shirt or jacket pock directly over the pacemaker).

If you think that interference may be occuring, turn off the device immediately. For other medical devices, consult with your physician or Medical Device manufacturer to determine you device may interfere with the medical device and to

This device includes a radio transmitter and receiver.

It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines and as referenced in FCC Part

Press on the power button for 3 seconds or longer to turn or

As such the Device is designed to send and receive low level 2. Power-off

 Device is working with SIM card and connected with app : active the remote power-on function in app. Device is not inserted with SIM card or connected with app : press to power off device.

device is using are valid, and month traffic is no less than 3

- Ensure the SIM card that your device is using matches to local network mode, contact with your device supplier if
- Main functions of device needs to be completed the setting in app from your smart phone, please ensure your phone is iPhone or leading brand Android phone.









screwdriver to take that is face-up to



out the protective lid. card slot slowly.

SIM card slot -

Android phone, Also you could search "Lite Guardian" in App Store or Google Play.

Power button

Scan below QR code to download app on your iPhone or

function work as well.)

2. Get Your account and Log-in

-

- 11

Login in with your

(PS:please allow app to access the permission of your 3.Device Binding with User ID phone and put "Lite Guardian" in white list to ensure

app to finish the device binding with app user ID Device ID could be found in [Register ID] function from



Historical Route

Geo-fences

Real-time Position Display

hish the setting of geo-fence round range function in app, when the device's wearer is out of fence range, your app will alert.

Ann could store multi GPS route record that ar

Start a voice chat between watch and phone (

Contacts List

Voice Chat

rilable to ready to one-touch dial anytime.

lot key to dial 3 emergency contacts.

Audio Monitoring on Watch

watch will pick your call automatically.

server at first 3. Check the function [caller ID] and unable to access 4. Check if the device ID number you input in to networking app is correct.

Do-Not-Distrurb Mode
You could set 3 periods that

s the default contact in app.

You could set 3 periods that watch not reach

Device No Manual Power-off Setting

charging cable with a soft dry cloth.

Device can not 1. Check if the SIM card is inserted properly

connect with 2. Check if the SIM card is out of service.

About Personal information

product is not bound by people without permission. We adopt technology and management measures to ensure the safety of network information, in accordance with the law to protect users' personal information, to ensure the

he power-off function is locked when device is on-line, only app user could power off device via

Here we describe the privacy practices for our devices applications, products, and services (the "Services"). You will learn about the data we collect, how we use it, the

measures we take to keep it safe.

1. If the battery is completely discharged, device cannot be turned on immediately when the charge

2. Allow a depleted battery to charge for a few

minutes before turning on. Use the charger to

charge the battery before using it for the first time.

WHY DEVICE NEEDS WORK WITH APPLICATION The device needs application to fully function, such as SIM number and etc.) to application, which ensure the

3. Before charging the battery, ensure that the charging contact pins of device is free of foreign

INFORMATION YOU PROVIDE US

material, such as sweat, liquid, or dust. Clean the

ACCOUNT INFORMATION

Some information is required to create an account on our Services, such as your name, email address, password. The account with us. You may also choose to provide othe types of information, such as a profile photo, biography. country information and etc.

Please install and use this product correctly. In order to

controls we give you over your information, and th

including GPS signals. We collect this type of data if you grant us access to your location. You can always remove our access using your device or mobile device settings. USAGE INFORMATION

When you access or use our Services, we receive certain

LOCATION INFORMATION

usage data. This includes information about your interaction with the Services, for example, when you view or search content, install applications or software, create or log into your account, pair your device to your account, or open or interact with an application on your device.

The Services include features that use precise location data.

Apple and its logo is a registered trademark of Apple Inc. Android. Google Play and its logo is a registered trademark of Alphabet Inc. The relative names, logos, and brands are property of their respective

Please visit www.lite-guardia for more product information.